



(I. Teil des Schaltbildes)



Ⓢ Rohrvoltmeter, Meßwerte bei MW(UKW)

Aus	1B	7A	FA	1W	1M	KW	UKW
0	1	2	3	4	5	6	7
1	8	9	10	11	12	13	14
2	15	16	17	18	19	20	21
3	22	23	24	25	26	27	28
4	29	30	31	32	33	34	35
5	36	37	38	39	40	41	42
6	43	44	45	46	47	48	49
7	50	51	52	53	54	55	56
8	57	58	59	60	61	62	63
9	64	65	66	67	68	69	70
10	71	72	73	74	75	76	77
11	78	79	80	81	82	83	84
12	85	86	87	88	89	90	91
13	92	93	94	95	96	97	98
14	99	100	101	102	103	104	105

ZF = 468 KHZ + 107 MHz



Gezeichnete Stellung: Gerät „out“

