



Schalter Nr.	1	2	3	4	5	6
Lang						●
Mittel	●		●	●		●
Pic-up					●	

ZF = 130 KHZ

BIENNOPHONE

