THE LINE Of the turn table

The home of the turn table

The home of the turn table

The home of the turn table

For more turntable manuals and setup information please visit www.vinylengine.com

DESCRIPTION

Model DP-30L II turntable is an improved version of the original Model DP-30L/30LS, featuring a light mass straight tonearm.

The electrical circuitry and rating are identical to those of original model.

Therefore, refer servicing to the original service manual as the electrical adjustments are exactly same.

PARTS LIST (Deviation from original Model DP-30L)

| Part Name | Part No. | Remark |
|--|---|-----------------------------------|
| CABINET ASS'Y ARM REST ASS'Y | 1038221203 1038221219 3158564013 | North America Europe/Australia |
| TONEARM ASS'Y BALANCE WEIGHT ASS'Y ARM BASE ASS'Y SHAFT RING | 3158825105 3158561113 3158 826104 3158 8 28005 | |
| SHIELD SHEET | 4148176009 | Phono output |
| HEAD SHELL ASS Y SHELL ACCESSORY | 3158553011 3158547001 | PCL-30 |
| CAM | 4248009005 | ARM LIFTING |
| VOLUME KNOE | 1138078220 | Speed adjust |
| RUBBER SHEET (turntable sheet) | [4218288005 4218288018 | UL recognized |
| INSTRUCTION MANUAL | 5118221006 | |
| CARTON CASE ASS'Y | 5018267005 | |

Other parts are same or compatibly modified.