


Änderungen vorbehalten!  
 ALTERATIONS RESERVED!  
 MODIFICAZIONI RISERVATE!  
 CON RISERVA DI MODIFICA!



Gezeigte Stellung LW  
 SHOWN IN POSITION FM  
 MONTRE EN POSITION FM  
 RAPPRESENTATO IN POS. FM

FM	87,5	-	108	MHz
MW	510	-	1620	KHz
LW	145	-	260	KHz
KW 1	5,9	-	6,3	MHz
KW 2	7,0	-	7,4	MHz
KW 3	9,4	-	10	MHz
KW 4	11,6	-	12,3	MHz
KW 5	15,0	-	15,75	MHz
KW 6	17,6	-	18,4	MHz

Netzanschluss  
 MAINS UNIT CONNECTION  
 PRISE BLOC - SECTEUR  
 PRESA ALIMENTATORE

Yacht-Boy 100

Yacht-Boy 120

**GRUNDIG** Yacht-Boy 100/120  
 (E750015-906.00)C

C	1, 24, 25, 28, 27, 2, 30, 32, 3, 29, 4, 5, 6, 31, 33, 34, 18, 19, 35, 36, 7, 8, 20, 43, 44, 90, 9, 37, 10, 45, 11, 12, 21, 13, 38, 47, 46, 14, 15, 39, 16, 48, 26, 22, 49, 23, 40, 41, 17, 72, 71, 73, 50, 70, 51, 74, 75, 76, 52, 77, 53, 65, 68, 54, 75, 66, 69, 55, 79, 59, 80, 67, 63, 81, 80, 64, 83, 86, 91, 61, 56, 82, 57, 58, 84, 82, 92,
R	1, 3, 2, 4, 14, 15, 5, 23, 24, 6, 7, 26, 25, 27, 16, 28, 8, 17, 29, 30, 18, 73, 10, 19, 9, 20, 21, 11, 12, 31, 13, 36, 65, 22, 34, 32, 33, 52, 53, 35, 54, 37, 55, 56, 57, 50, 38, 58, 39, 51, 63, 6, 0, 71, 59, 61, 47, 62, 40, 45, 64, 41, 66, 6, 9, 44, 72, 48, 49, 40, 46, 42, 43, 66, 67,