

2. Reproduction, Tracks 3-2.

Procedures are basically same as 1 above (Tracks 1~4) except Track Selector Switch slid to right (3~2) position and volume and tone adjustments made by right-channel controls.

* **Monitoring**

Connect stereo head-phone to Head-phone Jack of the recorder to monitor sound being recorded or enjoy privately reproduction of recorded sound through head-phone.

Head-phone best suited for this purpose is of 8Ω impedance type.

2. Reproduction d'un enregistrement sur les pistes 3-2.

Mettre le sélecteur à la position droite (3~2)..

Faire opérations suivantes comme un cas de reproduction de pistes (1~4).

Mettre toutes connexions et opérations contre les jacks droits et pour les boutons droits.

* **Suivre l'écoute**

A l'aide d'un écouteur personnel, vous pouvez faire le suivre l'écoute et vous pouvez goûter un enregistrement sans déranger les autres. Il est préférable de relier un écouteur personnel d'impédance de 8 ohms.

FAST FORWARD

When you want to get quickly to any particular portion of tape from where recording or playback may have to be started, press this F. FWD. button and tape wind very rapidly.

AVANCE ACCELEE

Si vous désirez passer un morceau de la bande, appuyer sur la touche F. FWD (Avance Accélée) et la bande s'avance rapidement.