



R	31,	72, 32,	81, 33, 1,2,	34,	41, 54,	73, 44, 82,	55,56, 45,42,43,	48,46,71,112,61,50,49,52,83,53,51,21,22,84,75,	57,58,	59, 60,								
C	91, 18, 5, 100,	101, 92,93,	28,	7, 113,	72,105, 103,1, 104, 8,	2,	47,49, 48,50,38,40,	51,	120,121,52,	73,123,	125,124,	61, 81, 84,122,	62,82,126,	131,	127,	75,	85,	128, 129, 130,
L	91,	17,19,92,18,20,	28,30,93,14,2,2,3,	13, 14,			33,37,39,34,38,40,		51, 55,			61,62,63,						81,82,83,84,



PŘEPÍNAČE P1-P2

ROZSAHY	SPOJENÉ DOTEKY P1	SPOJENÉ DOTEKY P2
KV	13-14, 15-17, 21-23	15-18, 23-24
SV	5-6, 9-10, 13-14, 15-17, 19-21	7-2-24, 5-6, 17-18-20,
DV	1-4, 15-17	3-2, 19-20,

Zapojení přijímače 845A „BESEDA“