



1004

SPARE PARTS LIST

FOR

DUAL RECORD CHANGER 1004


Type 12 B - Model A




STEIDINGER BROTHERS · ST. GEORGEN · BLACK FOREST · GERMANY

DUAL RECORD CHANGER 1004

Seen from above
with turntable and record spindle removed



Seen from below



R1 to R6 and K denote adjustment points

Spare parts list for DUAL Record Changer 1004

Type 12 B (A)

Number in Diagram	Number	Name of Part	Pieces per Unit
1	12 B - U 8	Switch lever, complete	1
2	11 A - U 19	Ball bearing, complete	1
3	11 A - U 21	Gear wheel	1
4	11 A - U 27	Engage bracket, complete	1
5	11 A - U 40	Voltags selector switch, complete	1
6	11 A - U 75	Striker cam, complete	1
7	11 A - U 87	Engage lever, complete	1
8	11 A - U 123	Withdrawal lever, complete	1
9	11 A - 18	Fixing bolts for switch lever	1
10	11 A - 195	Stop piece	1
11	12 A - U 17	Engage pin	1
12	12 A - U 61	Change bolt, complete	1
13	12 A - U 108	Lifting stud, complete	1
14	12 A - U 118	Dropping lever, complete	1
15	12 A - U 127	Clutch disc, complete	1
16	12 A - U 207	Main rail, complete, with roller	1
17	12 A - U 214	Drive wheel, complete	1
18	12 A - U 217	Distance rail, complete	1
19	12 A - U 221	Rail, complete	1
20	12 A - U 222	Clutch plate, complete	1
21	12 A - U 226	Feeler arm, complete	1
22	12 A - U 227	Lifting lever, complete	1
23	12 A - U 228	Brake lever, complete	1
24	12 A - U 230	Brake link, complete	1
25	12 A - U 234	End shut-off finger, complete	1
26	12 A - 92	Spring retainer	5
27	12 A - 112	Support bracket	1
28	12 A - 119	Spindle for dropping lever	1
29	12 A - 196	Intermediate wheel	1
30	12 A - 325	Lead cleat	2
31	12 A - 414	Spacing piece	1
32	12 A - 427	Bearing for spacing piece	1
33	12 A - 436	Switch lever	1
34	12 B - U 2	Main plate, complete	1
35	12 B - U 11	Trip assembly, complete	1
36	12 B - U 12	Over plate with muting switch	1
37	12 B - U 16	Cam set, complete	1
38	12 B - U 24	Switch link, complete	1
39	12 B - U 26	Switch escutcheon, complete	1
40	12 B - U 28	Switch lever, complete	1
41	12 B - U 38	Switch segment plate, complete	1
42	12 B - U 51	Under plate with bearing sleeve	1
43	12 B - U 54	Swing lever, complete	1
44	12 B - U 80	Push-button unit	1
45	12 B - U 84	Start lever	1
46	12 B - U 86	Stop lever	1
47	12 B - U 88	Repeat lever	1
48	12 B - U 96	Switch assembly, complete	1
49	12 B - U 98	Pusher, complete	1
50	12 B - U 100	Locking lever, complete	1
51	12 B - U 110	Housing for tilt plate, complete	1
52	12 B - U 112	Tilt plate, complete	1
53	12 B - U 118	Start link, complete	1
54	12 B - U 120	Stop link, complete	1
55	12 B - U 140	Overarm, complete	1
56	12 B - 46	Switch pointer	1
57	12 B - 110	Guide plate, large	1
58	12 B - 112	Pushrod I	2
59	12 B - 114	Pushrod II	1
60	12 B - 130	Bearing pin for push-button unit	1
61	12 B - 136	Start button	1
62	12 B - 138	Stop button	1

Number in Diagram	Number	Name of Part	Pieces per Unit
63	12 B - 140	Repeat button	1
64	12 B - 146	Guide plate, small	1
65	12 B - 184	Cover plate	1
66	12 B - 198	Repeat link	1
67	12 B - 200	Release link	1
68	12 B - 210	Cover disk for turntable	1
69	3250 / 13 a	Turntable, complete	1
70	3268 / 14	Mat for turntable	1
71	4650 / 9 a	Circlip for turntable	1
		Motor and Drive System	
	12 B - U 200	Motor complete, with drive unit	1
100	31 B - Ausf. E	Motor complete, without drive unit	1
101	11 A - U 48	Drive wheel, complete	1
102	12 B - U 32	Motor plate, complete	1
103	12 B - U 42	Intermediate wheel 78 rpm. complete	1
104	12 B - U 44	Intermediate wheel 45 rpm. complete	1
105	12 B - U 46	Intermediate wheel 33 rpm. complete	1
106	12 B - U 48	Intermediate wheel 16 rpm. complete	1
	12 B - 86	Retaining clip for intermediate wheels	4
	11 C - 138	Washer for intermediate wheels	4
107	31 B - 52	Motor pulley for 50 cps or	1
	31 B - 69	Motor pulley for 40 cps or	1
	31 B - 59	Motor pulley for 60 cps	1
108	31 B - U 2	Field coil I	1
109	31 B - U 3	Field coil II	1
110	31 B - U 25	Rotor	1
111	630 / U 1	Upper bearing, complete	1
112	31 B - U 14	Lower bearing, complete	1
		Connecting Leads etc.	
120	12 A - U 195	Pick-up lead, complete	1
121	12 A - U 198	Mains Lead, complete	1
122	12 A - U 252	Spring suspension Set of 4	
123	12 A - 293	Grub screw for overarm	1
		Assortment of springs	1
		Assortment of spring clips and washers	1
		Assortment of screws and nuts	1
		Pick-up	
130	12 A - U 94	Tone arm base with disc for base, complete	1
131	12 B - U 132	Tone arm base, incomplete (plastic component with bearing sleeve)	1
132	15 D - U 2	Tone arm complete, unattached	1
133	15 D - 14	Tone arm lead	1
		Springs	
F 1	5346 / 14	Tension spring for drive wheel	
F 2	11 A - 95	Tension spring for engage lever	
F 3	12 A - 116	Tension spring for change bolt	
F 4	12 A - 189	Support spring for tone arm	
F 5	12 A - 244	Tension spring for clutch plate	
F 6	12 A - 245	Wire spring	
F 7	12 A - 300	Disk spring for overarm	
F 8	12 A - 452	Tension spring for feeler arm	
F 9	12 B - 135	Tension spring for push rod	
F 10	12 B - 164	Tension Spring for pusher	
F 11	12 B - 164	Tension spring for stop link	
F 12	12 B - 202	Tension spring for main rail	
		Accessories	
150	11 A - 221	Short spindle	
	12 A - 312	Spring holder for large centre spindle	
151	12 A - U 182	Thin centre spindle, complete	
152	12 B - 208	7" Adapter	
153	13 A - Ausf. B 2	Large centre spindle AS 3	
154	14 A - U 40	Twin Sapphire Assembly DN 2	
154	14 A - U 50	Wide-range crystal cartridge CDS 3	
154	14 C - U 70	Pick-up head K	