# "TRADER" SERVICE SHEET 1535

SIX transistors and one crystal diode are employed in the Regentone BT16 and BT17 portable receivers. The circuit is wired on a printed panel and is designed for reception on M.W. and L.W. using an internal ferrite rod aerial. A socket on the side of the case provides for the connection of an external aerial if required.

Waveband ranges are 186-571m (M.W.) and 1053-1875m (L.W.). Power is obtained from two 9V batteries connected in series and the consumption is 18mA with no signal and 44mA at 50mW

Release dates and original prices: BT16, August 1961 £10 17s 3d; BT17, June 1961 £9 14s. Purchase tax extra.

# REGENTONE BT16 & BT17


# TRANSISTOR ANALYSIS

Transistor voltages shown in the table below were supplied by the manufacturer. They were measured with respect to chassis, not battery positive. The positive meter lead was connected to chassis.

### Transistor Table

Transistor	Emitter (V)	Base (V)	Collector (V)
TR1 OC44 TR2 OC45 TR3 OC45 TR4 OC81D TR5* OC81 TR6* OC81	1·2	1·1	7·7
	0·6	0·7	7·7
	0·9	1·2	7·7
	9·6	9·5	16·3
	7·6	7·9	16·9
	1·1†	1·0†	7·6

\*Matched pair. †With reversed polarity.




Appearance of model BT17


#### CIRCUIT DESCRIPTION

Coils L1, (L.W.) and L3 (M.W.) are the aerial tuning coils and are wound on a ferrite rod to form an internal aerial. TR1 operates as a self oscillating mixer and the signals are fed to its base via (Continued overleaf, col. 1)

R2 10kΩ 1 R3 3-9kΩ 1 R4 68kΩ 1 R5 8-2kΩ 6 R6 680Ω 1 R7 1-2kΩ 1 R8 4-7kΩ 1 R9 22kΩ 6 R11 1kΩ 1 R12 3-9kΩ 6 R13 5kΩ 1 R14 10kΩ 6 R15 — R16 1kΩ 6 R17 27kΩ 6 R17 27kΩ 6 R18 680Ω 6 R19 680Ω 6 R19 680Ω 6	R22   470Ω   C2	C12 0·1µF B3 C13 0·04µF C3 C14 0·1µF B2 C15 15pF B3 C16 25ppF B3 C17 0·1µF B2 C19 1µF C3 C20 — † C21 50µF C3 C22 100µF C3 C22 100µF C3 C24 0·01µF C3 C24 0·01µF C3 C24 0·01µF C3 C25 C24 0·01µF C3 C26 — A1 TC2 — A2 TC3 — B1  Coiis*  L1 15·0 A1 L2 5·0 A1 L3 — C1	L4 — A1 L5 — B1 L6 2-0 B2 L7 — B2 L8 — B2 L9 — B3 L10 — B3 L11 — B3 L12 — B3 L13 35-0 —   Miscellaneous*   Miscellaneous*   MR1 OA70 C3 S1-S6 — C1 S7, S8 — D2  * Approximate D.C. resistance in ohms. † No component.
---	-----------------	---	--



Circuit diagram of Regentone BT16 and BT17. Differences are confined to external appearance.



View of the receiver as seen when the back cover is removed. The aperture in the centre of the panel fits round the speaker magnet and the foil side of the panel is insulated from the speaker frame by a polythene wafer. When re-fitting the chassis after service, ensure that the poly-thene wafer is in position.

Circuit Description—continued coupling windings L4 and L5. L6 is tuned at local oscillator frequency and the oscillator voltage is fed via a coupling winding to TR1 emitter.

The resultant I.F. signal developed across L7 in TR1 collector is at 475 kc/s. TR2 and TR3 operate as I.F. amplifier stages, the output from TR3 being applied via L12 secondary winding to the detector diode MR1. TR1, TR2 and TR3 collectors are connected to tappings on their respective primary coils to match the output impedance. Rectified audio output from MR1 is fed to the volume control R13 and the positive carrier D.C. voltage is fed back via R5 to TR2 base as A.G.C. Driver transistor TR4 is connected between -9V and -18V supply and receives its base bias from the poten-

The output from TR4 is applied via phase splitting transformer T1 connected in its collector, to the output transistors TR5 and TR6. The latter form a single ended push-pull stage driving the loudspeaker, whose high impedance speech coil L13 is connected as the load imped-Negative feedback is applied via R29.

## **CIRCUIT ALIGNMENT**

Circuit alignment can be carried out with the chassis in the case.

Required.-An Equipment meter or a 0-10V A.C. voltmeter; an A.M. signal generator modulated 30 per cent; a  $0.1\mu\text{F}$  capacitor and a screwdriver-type trimming tool.

1.—Connect the output meter in place of the speaker speech coil or connect the A.C. voltmeter across the speech coil

(tags 3 and 8 on the printed circuit panel).

-Turn the tuning gang to minimum capacitance and the volume control to maximum. Connect the signal generator via the  $0.1\mu F$  capacitor to the base of TR1 (right-hand side slide switch pillar).

-Feed in a 475kc/s signal and adjust the cores of L11, L9 and L7 for maximum output.

-Disconnect the signal generator from TR1 and connect a loop of wire across the generator output leads. Place the loop a few inches from the ferrite rod. Switch to M.W. and tune receiver to 522m (calibration dot on scale).

5.—Feed in a 575kc/s signal and adjust L6 for maximum output.

6.—Tune receiver to 200m. Feed in a 1,500kc/s signal and adjust TC2 and TC1 for maximum output.

-Repeat operations 5 and 6 until no further improvement can be obtained.

-Switch to L.W. and tune receiver to 1,500m. Feed in a 200kc/s signal and adjust TC3 and L1 for maximum output.

#### **DISMANTLING**

BT16.-Loosen the two coin slotted screws about 4in, then holding the case, push against the two screw heads until the front and chassis protrude from the

Then remove the two retaining screws and pull the front and chassis from the

BT17.—Loosen the two coin slotted screws and remove the back cover

Remove the batteries and unsolder the connections to the external aerial socket. Unscrew the two hexagonal piliars securing the metal frame to the case. The chassis can now be removed to the extent of the speaker leads.

To re-assemble, reverse the above procedure ensuring that the polytnene wafer is in place.

# DRIVE CORD REPLACEMENT

About 36 inches of nylon braided glass yarn is required for a new drive cord. Turn the tuning gang to maximum capacitance and thread the cord as shown in our diagram below. This illustrates the our diagram below. This illustrates the fully assembled cord with the tuning gang in the maximum capacitance position.


#### 10DIFICATIONS

In early versions capacitors C24 and C24a were omitted and a  $0.01\mu F$  capacitor was connected across the primary winding of T1.

Alternative transistor types to those shown may be found on some chassis as

OC75 in place of OC81D.
OC74 (matched pair) in place of OC81. In the event of replacement becoming necessary either type can be used without any circuit changes

Battery.—Ever Ready PP7 (two).



Drive cord assembly as seen from the front.

Paris Garden, Stamford Street, London, S.E.!, and Published by Iliffe Electrical Publications, Ltd., Dorset House, Stamford Street, London, S.E.! Printed in Great Britain by Cornwall Press, L.d.,