






AB 2

AF 7

AL 4



Beleuchtg. u. Gramo-Schalt.



Schalter	1	2	3	4	5	8	9	10	11	13	14	15	16	17
Kurz	•			•	•				•	•				
Mittel			•	•		•		•				•	•	
Lang		•					•				•			•
⊙	•				•				•					

ZF = 128KHz

AM 1

Philips Serenata A