



DYNAMOTOR DM-34-(\*), AND DYNAMOTOR DM-36-(\*)



DYNAMOTOR DM-35-(\*), AND DYNAMOTOR DM-37-(\*)

FIGURE 49.—Schémas de disposition des convertisseurs.