

OC 613
T1


OC 612
T2

OC 612
T3


OC 604
T4

OC 604
T5


OC 604 spez.
T6
T7



EINSTELLEN MIT R 30
TO ADJUST WITH R 30



ZF / IF: 460 kHz



FERRITSTAB - FERRITE ROD AERIAL

	S1	S2	S3	S4	S5	S6	S7
TASTEN PUSH-BUTTON							
AUS							
M W							
L W							
TON							
TON							

STROME UND SPANNUNGEN GEMESSEN
BEI BATTERIE-SPANNUNG 6V MIT
UVA 33k OHM/V

CURRENTS AND VOLTAGES MEASURED
WITH B-SUPPLY OF 6V,
INSTRUMENT 33k OHMS/V

K 167

