

ALIGNMENT PROCEDURE

Output meter connection ..... Speaker voice coil  
Output meter reading to indicate .5 watt output..... 1.26 Volts  
Connection of generator ground lead..... Floating ground  
Position of volume control..... Fully clockwise

Position of Variable	Frequency of Generator	Dummy Antenna	Generator Output Connection	Trimmer Adjustment for Maximum Output	Function of Trimmer
Open 1400 Kc	455 Kc 1400 Kc	.05 $\mu$ f 50 $\mu$ f	Pin 7 12BE6 Antenna Clip (Blue wire disconnected)	A1, A2 A3 Rock Variable while making this adj. to track antenna	I. F. Oscillator
600 Kc	600 Kc	50 $\mu$ f	Antenna Clip (Blue wire disconnected)	Antenna Sections plates	Check point

Keep signal generator at a low value to prevent detuning by AVC action.

