



Figures in first column refer to parts in Diagrams.					
Item No.	Part No.	Description	Item No.	Part No.	Description
1	W -43567	Bulb—Dial Light	30	G173-36400	Socket Type 5Y3
	W -43568	Light Bracket		W -40911	Tube Shield
2	G132-32000	Ant. Coil, B. C.	31	G103-28807	Socket—Speaker
3	G133-32000	Ant. Coil, H. F.	32	257BP11 "B"	Speaker, Spec. No. 51-A-5 (Cab. 6K & 7KA)
1	G132-32002	Osc. Coil, B. C.		-42927	Cone for 257BP11 "B" Speaker
5	G133-32002	Osc. Coil, H. F.		-41473	O. P. Trans. for 257BP11 "B" Spkr.
6	G136-32004	1st I-F Assembly		-43539	Cardb'd Ring for 257BP11 "B" Spk.
7	G137-32004	2nd I-F Assembly		257BP18 "B"	Speaker, Spec. No. 51-A-8 (Cab. 7H & 7HA)
8	G33-33001	2 Sect. Var. Tuning Cond.(547 only)		-42927	Cone for 257BP18 "B" Speaker
8	G31-33001	2 Sect. Var. Tuning Cond.(517 only)		-43986	O. P. Trans. for 257BP18 "B" Spkr.
	B -43551	Dial Face (517 only)		-43539	Cardb'd Ring for 257BP18 "B" Spk.
	B -43729	Dial Face (Tel. Tun. Dial only)		462CP11 "M"	Spkr., Spec. No. 1-D-971 (Cab.6FF)
	W -43694	Disc—Center of Dial		-40405	Cone for 462CP11 "M" Speaker
	W -43693	Mask Ring (Dial)		-43989	O. P. Trans. for 462CP11 "M" Spkr.
	W -43778	Dial Support Ring		-43988	Field Coil for 462CP11 "M" Spkr.
	B -43544	Dial Glass Support		464BP15 "M"	Spkr., Spec. No. 1-D-1017(Cab. 7M)
	G1 -43564	Pullay Assembly		-43993	Cone for 464BP15 "M" Speaker
	W -43548	Drive Shaft		-43994	Field Coil for 464BP15 "M" Spkr.
	W -43549	Retaining Ring		-43995	O. P. Trans. for 464BP15 "M" Spkr.
	W -43550	Pointer (517 only)	33	W -43448	Switch Band Selector
	W -43542A	Drive Shaft Bracket	34	-36761	Resistor 40,000 Ohm 1/4W.
	W -43561	Drive Cable Spring	35	G1 -26719	Ant. and Ground Terminal Board
	-41582	Drive Cable	36	-43479	Power Trans. 110 V. 60 Cy.
9	G12-34002	Condenser .0005 Mf. H.F. Osc. Ser.		-43480	Power Trans. 110 V. 25 Cy.
10	-36541	Condenser .02 Mf. 160 V.		-43481	Power Trans. 220 V. 25 Cy.
11ABCD	W -28621	Condenser .02 Mf. 200 V.		-43449	Volume Control, 1 Megohm
12	W -34647	Condenser .01 Mf. 400 V.	37Z		Line Switch
13AB	G1 -34002	Condenser .00025 Mf. Molded	37Y		Trimmer Cond. B. C. Ant.
14	W -41081	Condenser 16 Mf. 250 V.	38Z		Trimmer Cond. H. F. Ant.
15	W -43450	Condenser 16 Mf. 200 V.	38Y		Trimmer Cond. B. C. Osc.
16	B -33906A	Power Cord and Plug	38X		Trimmer Cond. H. F. Osc.
17	-21237A	Resistor 60,000 Ohm 1/4W.	38W		Resistor 20,000 Ohm 1/4W.
18	-24814	Resistor 7,000 Ohm 1/4W.	40	W -30805	Condenser .01 Mf. 400 V.
19AB	-36688	Resistor 3 Megohm 1/4W.	41	-30137	Resistor 3,500 Ohm 1/4W.
20	-21455	Resistor 300,000 Ohm 1/4W.		G1 -43724	Tel. Tun. Escutcheon
21	-35601	Resistor 300,000 Ohm 1/4W.		W -43769	Pointer—Cabinet (547 only)
22	-23785	Resistor 500,000 Ohm 1/4W.		W -43554	Knob (1 required) Small
23	W -28589	Resistor 350 Ohm 1/4W. Flex.		W -43625	Knob (2 required) Large
24	W -33012A	Resistor 40 Ohm 1/4W. Flex.		W -43553	Rubber Mtg. Foot
25	W -24537	Resistor 60 Ohm 1/2W. Flex.		W -43552	Clamp—Speaker Plug
26	G156-36400	Socket Type 6A8		W -43726	Celluloid Disc (547 only)
27	G171-36400	Socket Type 6U7			
28	G160-36400	Socket Type 6Q7			
29	G172-36400	Socket Type 6R6			