



WIRING DIAGRAM—MODEL 726

The Crosley Corp.

PARTS LIST—MODEL 726

Figures in first column refer to parts in Diagram					
Item No.	Part No.	Description	Item No.	Part No.	Description
1ABC	W -37922	Dial Light	44	-36319	Resistor, 75,000 Ohm 1/4 W.
2	G3 -37965	Socket Assy. Dial Light	45A	-38428	Resistor, 60,000 Ohm 1/4 W.
3	G10 -32000	Coil Ant. 540-1800 Kc.	45B	-35928	Resistor, 60,000 Ohm 1/4 W.
4	G11 -32000	Coil Ant. 1800-6000 Kc.	46	-38321	Resistor, 400,000 Ohm 1/4 W.
5	G76 -32001	Coil R F 540-1800 Kc.	47	-38623	Resistor, 750,000 Ohm 1/4 W.
6	G80 -32001	Coil R F 1800-6000 Kc.	48	-36322	Resistor, 500,000 Ohm 1/4 W.
7	G90 -32001	Coil R F 6-18 Mc.	49	-37377	Resistor, 20,000 Ohm 1 W.
8	G115 -32002	Coil Osc. 590-1800 Kc.	50	-35928	Resistor, 150,000 Ohm 1/4 W.
9	G121 -32002	Coil Osc. 1800-6000 Kc.	51A	-35601	Resistor, 300,000 Ohm 1/4 W.
10	G122 -32002	Coil Osc. 6-18 Mc.	51B	-35601	Resistor, 300,000 Ohm 1/4 W.
11	G121 -32001	1st IF Assy.	51C	-35601	Resistor, 300,000 Ohm 1/4 W.
12	G120 -32004	2nd IF Assy.	52A	-35930	Resistor, 200,000 Ohm 1/4 W.
13	W -36055	Condenser, 35Mf. 400V.	52B	-35930	Resistor, 200,000 Ohm 1/4 W.
14	W -36057	Condenser, 40Mf. 300V.	52C	-35930	Resistor, 200,000 Ohm 1/4 W.
15	W -410R1	Condenser 16Mf. 250V.	53	W -20127	Resistor, 450 Ohm 1/2 W. Flex.
16A	W -26541	Condenser, 02Mf. 100V.	54	W -23012A	Resistor, 40 Ohm 1/2 W. Flex.
16F	W -26541	Condenser 02Mf. 100V.	55	W -6705	Resistor, 3500 Ohm 1 W.
17	W -30805	Condenser, 01Mf. 400V.	56A	W -28589	Resistor, 350 Ohm 1/2 W. Flex.
18	W -35936	Condenser, 05Mf. 200V.	56B	W -28589	Resistor, 350 Ohm 1/2 W. Flex.
19	W -32790B	Condenser, 03Mf. 400V.	56C	W -28589	Resistor, 350 Ohm 1/2 W. Flex.
20	W -32778	Condenser, 01Mf. 400V.	57	W -77781	Resistor, 16,500 Ohm. (Cand Ohm)
21A	W -35139	Condenser, 004Mf. 400V.	57X		Resistor, 16,500 Ohm.
21B	W -35139	Condenser, 004Mf. 400V.	63A	G151 -36400	Socket Type 6K7
21C	W -35139	Condenser, 004Mf. 400V.	63B	G151 -36400	Socket Type 6K7
22	W -29621	Condenser, 02Mf. 200V.	64	G156 -36400	Socket Type 6A8
23	W -23615	Condenser, 03Mf. 200V.	65	G156 -36400	Socket Type 6H6
24	W -30323	Condenser, 01Mf. 200V.	66	G158 -36400	Socket Type 6F5
25	W -29619	Condenser, 004Mf. 200V.	67	G165 -36400	Socket Type 6N6
26	W -25435	Condenser, 003Mf. 400V.	68	G154 -36400	Socket Type 5Z4
27A	G2 -34002	Condenser, 0001Mf. (Mica)	69	C -40910A	Band Selector Switch
27B	G2 -34002	Condenser, 0001Mf. (Mica)	70Z		Fidelity Switch
28	G3 -34002	Condenser, 0001Mf. (Mica)	70Y	B -42387C	Fidelity Switch
29	G3 -34002	Condenser, 0005Mf. (Mica)	71	-415C13	Line Switch
30	G6 -34002	Condenser, 00025Mf. (Mica)		-42883	Speaker "M" Spec. 1D640
31	G20 -34000	Condenser, 400Mf. (Mica)		-40406	Cone Assy. For Above
32	G7 -34003	Condenser, 1450Mf. (Mica)		-42885	Field Coil Speaker
33	40769	Condenser, B. C. Osc. Series Trim	72	G27 -26719	Ant. & Cnd. Terminal Assy.
34	W -35951	Condenser, 3 Section Trimmer	73	-42260	Power Trans 60 Cy 110 V.
35	G32 -34002	Condenser, 3 Gang Var. Tuning	74	-42261	Power Trans 25 Cy 110 V.
MC33	C -42255	Dial Drive Assy.		-42501	Volume Control 3 Meg
	C -42491	Dial Glass (Calibrated)			Misc. Parts
	-42900	Drive Unit	C -42045		Escutcheon
	W -42597	Dial Mark. (Cardboard)	B -42043		Escutcheon Rubber
	Dial Hand Pointer		D -30		Screws - Escutcheon Mtg.
	Dial Hand, Time Log		C -42044		Lens - Escutcheon
	W -40486	Pointer Mtg. Screw	W -40230B		Emblem
36	G1 -34002	Condenser, 0025Mf. (Mica)	W -32620		Nut - Emblem Mtg.
37	W -30270	Condenser, (K) Mf. 400V.	W -35117		Rubber Mtg. Foot
40	H -33906A	Power Cord & Plug	W -37339		Knob (2 Req.)
41	G3 -35986	Cable, Speaker	W -40192B		Knob, B. S. Sw. (1 Req.)
42	37245	Resistor, Mex Ohm 1/4 W.	W -42490		Knob, S. S. (1 Req.)
43	35600	Resistor, 100,000 Ohm 1/4 W.	W -6-NG		Cabinet