

PARTS LIST — MODEL 1118

Figures in first column refer to parts in Diagrams.

Item	Part No.	Description	Item	Part No.	Description
1	G97—32001	Pre-Selector Coil, B.C.	35	—35600	Resistor, 100,000 Ohm $\frac{1}{4}$ W. Carb.
2	G138—32000	Antenna Coil, B.C.	36	—36320	Resistor, 120,000 Ohm $\frac{1}{4}$ W. Carb.
3	G151—32000	Antenna Coil, Police	37	—34018	Resistor, 200,000 Ohm $\frac{1}{3}$ W. Carb.
4	G150—32000	Antenna Coil, H.F.	38	—34020	Resistor, 250,000 Ohm $\frac{1}{3}$ W. Carb.
5	G139—32002	Oscillator Coil, B.C.	39A	—23785	Resistor, 500,000 Ohm $\frac{1}{3}$ W. Carb.
6	G154—32002	Oscillator Coil, Police	39B	—23785	Resistor, 500,000 Ohm $\frac{1}{3}$ W. Carb.
7	G153—32002	Oscillator Coil, H.F.	40	—37590	Resistor, 750,000 Ohm $\frac{1}{3}$ W. Carb.
8	G161—32004	1st I-F., 455 Kc. Assy.	41	—21454	Resistor, 1 Megohm $\frac{1}{3}$ W. Carb.
9	G154—32004	2nd I-F., 455 Kc. Assy.	42	—26577	Resistor, 3 Megohm $\frac{1}{3}$ W. Carb.
10	W—44054	Condenser, 30 Mf. 350 V.	43	—44165	Resistor, 5,000 Ohm $\frac{1}{2}$ W. Carb.
11	W—36057B	Condenser, 40 Mf. 300 V.	44	—4921C	Resistor, 10,000 Ohm 1W. Carb.
12	G1—44886	Condenser, Bimetal Temp. Control	45	—44008	Resistor, 10,000 Ohm 2W. Carb.
13A	G2—34002	Condenser, .0001 Mf. Molded	46	W—37631	Resistor, 32 Ohm $\frac{1}{2}$ W. Flex.
13B	G2—34002	Condenser, .0001 Mf. Molded	47	W—45381	Resistor, 300 Ohm 2W. Flex.
13C	G2—34002	Condenser, .0001 Mf. Molded	48	W—23013	Resistor, 2,000 Ohm $1\frac{1}{4}$ W. Flex.
14	W—35936	Condenser, .05 Mf. 200 V.	49		
15A	W—28621	Condenser, .02 Mf. 200 V.	50	G178—36400	Socket, 8 Prong Octal.
15B	W—28621	Condenser, .02 Mf. 200 V.	51		
15C	W—28621	Condenser, .02 Mf. 200 V.	52	G103—28807	Socket, Speaker
15D	W—28621	Condenser, .02 Mf. 200 V.	53	G16—28807	Socket, Push Button Cable
16	W—41461	Condenser, .0014 Mf. 200 V.	54	W—41007	Cable Clamp, P. B. Cable
17	W—28619	Condenser, .006 Mf. 200 V.	55	W—40911	Tube Shield
18A	W—22688	Condenser, .1 Mf. 400 V.	56	671BP-18-"M"	Speaker, Spec. No. 1-D-1180
18B	W—22688	Condenser, .1 Mf. 400 V.	57	—45184	V. C. and Cone Assembly
18C	W—22688	Condenser, .1 Mf. 400 V.		—45185	Field Coil (515 Ohm)
19	W—23615	Condenser, .05 Mf. 400 V.		—44678	Output Transformer
20	W—30805	Condenser, .01 Mf. 400 V.		—43680	Cone Mounting Ring
21A	W—35139	Condenser, .004 Mf. 400 V.		W—24715	Elastic Mounting Nuts
21B	W—35139	Condenser, .004 Mf. 400 V.		W—22985	Rubber Washer
22	—40769	Condenser, B.C. Osc. Series Trimmer		W—46804	Spacer
23	G23—34000	Condenser, .001560 Mf. Pol. Osc. Fixed Trimmer		W—24865	Steel Washer
24	G20—34000	Condenser	58	—44049	Band Selector Switch
25	W—35951A	3 Section Shunt Trimmer Assy.	59	G1—44628	Switch, Discriminator, Assy.
26	G60—33002	3 Section Var. Tuning Cond. (1118)	60	G2—44628	Flexible Coupling
26	G62—33002	3 Section Var. Tuning Cond. (1128)		—44024B	Tone Control (300,000 Ohm) and Switch
	W—44907A	Idler Pulley (1118)	61	—46086	Switch, Local Distance (1128)
	W—44908	Idler Mtg. Stud (1118)	61	—44665A	Switch, Local Distance (1118)
	D—46239	Dial Face (Glass) (1128)	62	G27—26719	Ant. and Gnd. Terminal Assy.
	C—46094	Dial Glass Support (1128)	63	—44910	Power Transformer, 110 V. 60 C
	W—46099	Dial Glass Clip (2) (1128)		—44915	Power Transformer, 110 V. 50 C
	W—46096	Dial Glass Clip, R.H. (1128)		—44916	Power Transformer, 220 V. 50 C
	W—46095	Dial Glass Clip, L.H. (1128)		—45527	Power Transformer, Universal
	—46203	Dial Pointer (1128)	64	—44702	Volume Control, 1 Megohm
	W—46097	Dial Pointer Guide (1128)	65A	G8—45228	Push Button—Cable and Plug (R.H.) (1118)
	G—41582	Drive Cord (50-Inch) (1128)	65B	G9—45228	Push Button—Cable and Plug (L.H.) (1118)
	W—46941	Dial Glass Cushion (1128)		W—45478	Trip Bar and Connecting Link Switch) (1118)
	G13—43564	Pulley and Hub Assy. (1128)		G37—26719	Phono Terminal Assy.
	MG44—46080	Idler Pulley and Brkt. Assy. (1128)	66	B—33960A	Line Cord and Plug
	W—44989	Cord Tension Spring (1128)	68	W—43567	Dial Light Bulb, 6-8 Volt (1118)
	W—46477	Tubing—Drive Shaft (1128)	71	W—37922	Dial Light Bulb, 6-8 Volt (1128)
	W—45448	Drive Belt (1128)	71	G9—44363	Dial Light Socket Assy.
	W—44907B	Idler Pulley (Dual) (1128)	72	MG45—46081	Push Button—Cable and Plug (1128)
	W—44908	Idler Stud (1128)			
	D—46949	Dial Glass (Foreign Only) (1128)			
	W—46290	Drive Cord Clamp (1128)			
27	W—41598	Condenser, 50 Mf. 25 V.			
28	—44516	Condenser, Pre-Select Shunt	73		
29	MG105—44879	Motor Assembly (50-60 Cycle)		7P	Cabinet (1118)
	—45168	Motor		B—45652A	Escutcheon (Dial) (1118)
	W—45165	Motor Foot		—45667	Escutcheon (Push Button) L.H.
	W—45164	Motor Mounting Bracket		—45666	Escutcheon (Push Button) R.H.
	W—20800	Shakeproof Washer		W—44380B	Knob, Vol. Cont. and Tuning (2)
	—6875	W. H. Machine Screw, $\frac{3}{16}$ " Long		W—44426A	Knob, T. C.—L. D. Sw. and B. C (3) (1118)
	—6876	W. H. Machine Screw, $\frac{1}{4}$ " Long		W—44871A	Push Button (Bakelite) (1118)
	—44497	Headed Bushing—Brkt. Mtg.		B—44876A	Switch (Push Button) Only
	W—36180	Rubber Sleeve—Brkt. Mtg.		8Q	Cabinet (1128)
30	—42401A	Resistor, 99 Ohm $\frac{1}{4}$ W. Ins.		8QA	Cabinet (1128)
31	—22196	Resistor, 20,000 Ohm $\frac{1}{3}$ W. Carb.		C—46228C	Escutcheon (1128)
33	—21237A	Resistor, 60,000 Ohm $\frac{1}{3}$ W. Carb.		—46360A	Knob, Vol. Cont. and Tuning (2)
34A	—21875	Resistor, 100,000 Ohm $\frac{1}{3}$ W. Carb.		—46362A	Knob, T. C.—L. D. Sw. and B. C (3) (1128)
34B	—21875	Resistor, 100,000 Ohm $\frac{1}{3}$ W. Carb.		W—45171	Push Button (Bakelite) (1128)
34C	—21875	Resistor, 100,000 Ohm $\frac{1}{3}$ W. Carb.		B—46221	Switch (Push Button) Only (1128)
				W—44876A	Celluloid Cover (Button)