


NOTE: CORRECT SPEAKER CONNECTIONS MUST BE OBSERVED.




EMERSON RADIO

Model 877, Chassis 120392B

Emerson Radio

Model 877, Chassis 120392B

NOTE: RESISTORS ARE IN OHMS (K=1000 OHMS) AND 1/2 WATT UNLESS OTHERWISE NOTED. CAPACITORS GREATER THAN 100 μF ARE IN MFD. CAPACITORS LESS THAN 100 μF ARE IN PFD. UNLESS OTHERWISE SPECIFIED * USED ON SOME CHASSIS.



NOTE: SIGNIFIES CERAMIC OR MICA CAPACITORS. SIGNIFIES TUBULAR CAPACITORS.

NOTE: VOLTAGES INDICATED AS FOLLOWS:
1. FM SWITCH POSITION
2. V-6 (B) AND V-7 READINGS ARE WITHIN 10% OF "AM" POSITION READING WHEN SW-3 IS IN PHONO POSITION.