



Parts List Model 4B1

Figures in first column correspond to figures in diagram

1	W	—28621	0.02 Mfd. 200 Volt	22	W	—28621	0.02 Mfd. 200 Volt
2	G27	—32000	Antenna Coil	23	W	—25572	{ 0.0005 Mfd. 400 Volt
3	G6	—33001	Variable Cond.	24			{ 0.0005 Mfd. 400 Volt
4	W	—5382	0.00025 Mfd.	25		—26577	3 Meg.
5		21875	100,000 Ohms	26	G9	—32004	1st I. F. Trans.
6	G9	—32002	Oscillator Coil	27			
7				28		21455	300,000 Ohms
8	W	—28622	{ 0.1 Mfd. 200 Volt	29	W	—28621	0.02 Mfd. 200 Volt
9			{ 0.1 Mfd. 200 Volt	30		21454	1 Meg.
10	W	—30321-A	1.0 Mfd. 160 Volt	31		24814	7,000 Ohms
11				32	W	—28619	0.006 Mfd. 200 Volt
12				33		21M	Speaker
13		27121	5,000 Ohms	34			
14	W	—33922-A	{ Volume Control	35	W	—29910-A	0.25 Mfd. 200 Volt
15			{ 3 P. S. T. Switch	36	W	—28621	0.02 Mfd. 200 Volt
16	W	—23013	2,000 Ohms	37	G55	—27975	1A6 Socket
17	G5	—23300	0.6 Ohm	38	G31	—27975	34 Socket
18	G2	—29237	Cable & Marker Assem.	39	G4	—33070	1A6 Socket
19	W	—21452	1,100 Ohms	40	G36	—27975	33 Socket
20	G13	—32004	2nd I. F. Trans.	41		23785	500,000 Ohms
21	G5	—33005	I. F. Trimmer Cond.	42		24990	25,000 Ohms