

CROSLEY

Chassis 75E

Models: E-75 CE, E-75 RD, E-75 GN, E-75-TN


CHASSIS 90E

Models: E-90WE, E-90CE, E-90GY, E-90RD, E-90BK


Chassis 85E

Models: E-85 CE, E-85 RD, E-85 GN, E-85 TN

SOCKET VOLTAGE CHART



- NOTES:
1. BOTTOM VIEW OF TUBE SOCKETS
2. VOLTAGES MEASURED WITH AN ELECTRONIC VOLTMETER FROM SOCKET LINES TO G
3. MEASURED WITH THE VOLUME CONTROL AT MINIMUM, 90 SIGNAL INTO THE LOOP, TUNING GANG CLOSED
4. WJ - WIRING JUNCTION
NC - NO CONNECTION
- AC VOLTAGES
9. LINE VOLTAGE, 175V, 90V AC
6. SOCKET VOLTAGE TOLERANCE $\pm 10\%$



CHASSIS - TOP VIEW

