




INTERNATIONAL RADIO CORP. MODELS 1129, 1149
MODEL 1159



FOR ALIGNMENT AND VOLTAGE, SEE INDEX



The following tubes are employed:

- | | |
|-----------------------------|----------------------|
| 6A7—1st Detector-Oscillator | 41 — Audio Output |
| 6D6—I.F. Amplifier | 200R — Ballast tube |
| 76 — 2nd Detector | 25Z5 — Rectifier |
| 76 — 1st Audio | 250R — Ballast tube |
| 76 — Inverter | 300R4—Regulator tube |
| 41 — Audio Output | |