



- TO REMOVE CABINET
1. Remove 2 cab. rear screws & separate front & back.
  2. Chassis can remain on cabinet front for trouble-shooting and alignment.  
(Knobs are removed by releasing captive clips with a screwdriver.)

**GENERAL ELECTRIC**  
Model T210A

BOTTOM VIEW