



**MODELS 5A410, 5A430
CHASSIS 4501, 4504**

* Make a two or three turn loop about 12 inches in diameter. Connect to output terminals of the signal generator. Place this loop in a plane parallel to the receiver loop antenna and about a foot away from the receiver loop.