



BAND-SWITCH SHOWN IN EXTREME
COUNTER-CLOCKWISE POSITION AS VIEWED
FROM KNOB END.
FRONT SIDE OF SECTION #1 IS NOT USED
OR SHOWN.