


MODEL S7399-1



**NOTE: MENTION THE CODE No. A-365
WHEN ORDERING PARTS.**

ELECTRICAL PARTS

Diagram Number	Part Number	Description	List Price
47	119324	Condenser—padder	\$0.38
48A-48B	500057	Switch—band	\$1.20
49	500108	Coil—compensator	.50
50 to 53	500127	Condenser—Push button trimmer (540-1000 KC)	.24
54	500131	Transformer—1st I.F.	1.00
55A-55B-55C	500133	Condenser—three section trimmer	.50
56	500135	Coil—B.C. & S.W. Osc.	.75
57	500137	Transformer—power (60 cycles)	3.50
	500202	Transformer—power (25 cycles)	5.60

Diagram Number	Part Number	Description	List Price
58	500147	Coil—short wave antenna	\$0.55
59	500179	Loop antenna	2.50
60	M-500180	Speaker—dynamic (8")	6.50
61	M-500194	Transformer—output for M-500180 speaker	1.75
62	M-500195	Cone & Voice coil for M-500180 speaker	1.70
63A-63C	500201	Condenser—electrolytic A=20 mfd.—350 V. B=20 mfd.—350 V. C=20 mfd.—25 V.	1.35

Diagram Number	Part Number	Description	List Price
1	85339	Condenser—mica 280 mmfd.	\$0.20
2-3-4	83783	Condenser—mica 110 mmfd.	.20
5	85061	Condenser—mica 51 mmfd.	.15
6	88587	Condenser—mica .0042 mid.	.35
7	110510	Condenser—wire 3 mmfd.	.12
8-9	110552	Resistor—carbon 47,000 ohms $\frac{1}{4}$ watt	.12
10	110553	Resistor—carbon 220,000 ohms $\frac{1}{4}$ watt	.12
11	110557	Resistor—carbon 4,700 ohms $\frac{1}{4}$ watt.	.12
12	110559	Resistor—carbon 470,000 ohms $\frac{1}{4}$ watt.	.12
13-14	110564	Resistor—carbon 100,000 ohms $\frac{1}{4}$ watt.	.12
15	110570	Resistor—carbon 2.2 meg. $\frac{1}{4}$ watt	.15
16	110580	Resistor—carbon 180 ohms $\frac{1}{4}$ watt.	.12
17-18	110629	Dial light bulb—3.30 volt.	.15
19	112952	Resistor—carbon 3,300 ohms $\frac{1}{4}$ watt.	.10
20	112975	Resistor—carbon 10 meg. $\frac{1}{4}$ watt.	.12
21	115078	Resistor—560 ohms $\frac{1}{4}$ watt.	.12
22-23	116819	Condenser—.05 mfd. 600 volt.	.20
24	117075	Resistor—300 ohm 1 watt W.W.	.16
25	118805	Resistor—carbon 10,000 ohms 1 watt.	.12
26	119024	Transformer—2nd I.F.	1.15
27	119132	Condenser—trimmer	.20
28 to 33	119193	Condenser—.01 mfd. 600 volt.	.15
34	119289	Switch—tone	.60
35	119414	Condenser—.02 mfd. 600 volt.	.15
36	119603	Push Button Switch	2.30
37	119663	Condenser—Push Button trimmer (750-1375 KC.)	.24
38	119664	Condenser—Push Button trimmers (980-1600 KC.)	.24
39-43A-43B	119779	Volume control— $\frac{1}{2}$ meg. (with switch).	1.25
44-44A-44B	119812	Gang condenser	2.65
45-46	119817	Condenser—.004 mfd. 600 volt.	.15