


Emerson

Modèles FY-434 (châssis FY)
FY2-434 (châssis FY2)

OUTPUT TRANSFORMER
ON SPEAKER

SPEAKER PLUG
(View looking at pins)

SEE ENCIRCLED NUMBERS ON
SCHEMATIC FOR CONNECTIONS



USE DOTTED PORTIONS WITH
A.C.-D.C. MOTOR ONLY.
USE R12 WITH A.C. MOTOR ONLY

FEMALE PLUG
ON CHASSIS.

POLARIZED MALE PLUG
ON CABLE FROM MOTOR.

$M = 1,000 \Omega$

LINE SWITCH ON
VOLUME CONTROL

TRANSFORMER
BLUE RED GREEN BLACK
FEEDBACK

TO A.C. OR
D.C. LINE