

SENTINEL RADIO CORP



One 4½ Volt "A" Battery, such as SENTINEL Type A38, or

Ray-O-Vac P83A or Eveready No 746, etc

One 67½ Volt "B" Battery, such as SENTINEL Type B7634, or Ray-O-Vac 4367 or Eveready No 467, etc

**VOLTAGE TABLE**  
(BOTTOM VIEW OF CHASSIS)

[illegible]