



MODELS 6106, CHASSIS
101.662-2E; 6106A,
CHASSIS 101.662-4E;
6111, CHASSIS
101.662-3C; 6111A,
CHASSIS 101.662-5F



BAND-SWITCH SHOWN
AT 2ND POSITION CLOCKWISE.
SHORT WAVE BAND
6-18 MC



BAND-SWITCH SHOWN
AT 1ST POSITION.
BROADCAST BAND
540-1700 KC

NOTE :-

ALL ITEMS MARKED WITH
AN * APPLY ONLY TO
MODELS 6106A & 6111A