


PUSH BUTTON TRIMMERS		
NO	5001-6001-602	502
A&B	HI	HI
C&D	MED	HI
E&F	MED	MED
G&H	LOW	MED
I&J	LOW	LOW
K&L	LOW	LDW

STEWART-WARNER
01-6G et 01-6G-Z

SOCKET VOLTAGES

RADIO-PHONO SWITCH IN RADIO POSITION	NO SIGNAL CONDITION



NOTE A: Bias on 6F6G output tube is —18 volts measured across resistors 29, 6 and 8.

NOTE B: Bias on 6SQ7 grid is -1.5 volts measured across resistor 6.