


Sentinel

MODELS 335PM,
335PW, 335PI, 335PG, 1U-335PM,
1U-335PW, 1U-335PI, 1U-335PG



FOR BATTERY OPERATION THE AC LINE CORD PLUG MUST BE FIRMLY INSERTED INTO THIS RECEPTACLE

TO REMOVE CHASSIS FROM CABINET
1. REMOVE BATTERIES.
2. UNSOLDER ANTENNA WIRES C AND D.
3. REMOVE SCREWS E AND F.

FOR AC-DC OPERATION, OPEN BACK, PLACE LINE CORD IN NOTCH AND CLOSE BACK

