



TELE KING COMBINATION
CHASSIS No. RE-2A

INTERMEDIATE FREQUENCY 455 K.C.

BOTTOM VIEWS OF ALL SOCKET CONNECTIONS

RADIO-PHONO-TV SWITCH (S2) SHOWN IN RADIO (MOST CW) POSITION

SHIELDED LEADS

*** TRIMMER ON GANG**

5 TUBE AM RADIO MODEL RE-2A USED IN COMBINATIONS

Schematic Symbol No.	Description	Teeking Part Reference No.
C1, C2	01 Mfd 400V	CP 411
C3	02 Mfd 400V	CP 412
C4	1 Mfd 600V	CP 413
C5	0047 Mfd 500V	CP 414
C6	25 Mfd 50V Electrolytic	CP 427
C7	05 Mfd 600V	CP 615
C8	50 Mfd 150V Electrolytic	CP 619
C9	50 Mfd 150V Electrolytic	CP 615
C10	50 Mfd 150V Electrolytic	CP 615
C11a, C11b	2-Gang Variable Cond. w/ Drum	CP 115
L1	Cast Loop Antenna	L 105
L2	Cast Oscillator Coil	L 105
PC-51	Printed Circuit	PC 51
PC-150	Printed Circuit	PC 150
PC-151	Printed Circuit	PC 151
P-25	Volume Control w/ Switch 2 Megohms	P 25
P-26	Tone Control w/ Switch 2 Megohms	P 26
R1	22K ohms 1/2W	RC 223-2
R2	22K ohms 1/2W	RC 223-1
R3	22K ohms 1/2W	RC 223-1
R4	470K ohms 1/2W	RC 470-2
R5	150 ohms 1/2W	RC 151-1
R6	220K ohms 1/2W	RC 224-2
R7	1000 ohms 2W	RC 100-7
T-1	117V Transformer	TE 131-4
T-132	Audio Output Transformer	T 132