

MOTOROLA

MODELS

CHASSIS

5K118

HS-673

5K11M

HS-673

5K11MC

HS-673

5K11W

HS-673

NOTES

CAPACITORS - Decimal values in MF, all others in MWF unless otherwise specified.

VOLTAGES - Measured from point indicated to chassis with a VTVM.
+10%. No signal in.

S1 & S2 conn details viewed from indicated sides with arrow indicating clockwise rotation as viewed from front of control

S1 SHOWN IN PHONO POSITION IR|AA|

S2 SHOWN IN EXT SPKR POSITION

 = Chassis = Record changer base

