


# MOTOROLA


## MODELS

## CHASSIS


5T21W-1	HS-625
5T22M-1	HS-625
5T22R-1	HS-625
5T22W-1	HS-625
5T22Y-1	HS-627
5T23N-1	HS-627
5T23P-1	HS-627
5T23W-1	HS-627
5T23Y-1	HS-627






5T21-1 SERIES



5T23-1 SERIES



## ALIGNMENT LOCATIONS



# MOTOROLA