


Motorola

MODELS

52CW1
52CW2
52CW3
52CW4

CHASSIS

HS-329



CLOCK OPERATION

The clock will start as soon as the receiver is plugged into an electrical outlet. To set the hands to the correct time, pull out knob "A" and rotate it in a clockwise direction only.

AUTOMATIC RADIO OPERATION

The clock controls may be pre-set to turn the radio on

automatically at any time up to ten hours in advance.

Rotate knob "C" clockwise to the desired time on the automatic time dial scale. Rotate knob "B" to the "AUTO" position. At the pre-set time the radio will begin to play.

If the radio has been turned on automatically and is left unattended, with knob "B" in the "AUTO" position, it will shut off after approximately two hours. To permit continuous operation, rotate knob "B" to the "ON" position.

Alignment information continued on the next page, over.