

NOTE A—Hold the tuning knob and turn the film drum until it is at the 1500 KC mark

NOTE C—At the bottom of the permeability tuning unit can be seen six "W" openings. Insert the end of a pair of long nose pliers or a screwdriver in the "W" opening of the proper button and adjust the position of the antenna (rear) coil by twisting the pliers or screwdriver until maximum output is obtained.

ON-OFF SWITCH

NOTICE—Re-alignment is necessary if glass tubes are replaced by their equivalent in metal tubes, or vice versa, in the R.F. and I.F. stages.

FOR TUNER DATA
SEE INDEX

