



Socket voltages are shown on the schematic diagram at the tube socket terminals. All voltages except those for the heater and dial lamp are between the socket terminal and "X" point.

The readings were taken with a 1000 ohm-per-volt meter and all plate and screen voltages read on a 500 volt scale. Conditions of measurement are:

Line voltage ..... 117 volts AC  
Volume control ..... maximum  
Signal input ..... none



MONTGOMERY WARD  
CHICAGO, U. S. A.  
MODEL 64 WG-1804A