



WARDOS

MODELS 64WG-1511A, 64WG-1512A, 64WG-1809A

SIGNAL GENERATOR		Coupling Capacitor	DIAL SETTING	ADJUST TRIMMERS TO MAXIMUM OUTPUT IN ORDER SHOWN (See Trimmer Illustration)
Frequency Setting	Connection to Receiver			
455 kc	Control Grid 12SF7-I.F. (Prong No. 2)	.1 mfd	1600 kc	2nd I.F. (C10) & (C11)
455 kc	Control Grid 12SA7-1st Det. (Prong No. 8)	.1 mfd	1600 kc	1st I.F. (C7) & (C8)
1400 kc	Control Grid 12SA7-1st Det. (Prong No. 8)	.1 mfd	1400 kc Index Line. See Note A	Oscillator (C25)
1400 kc	External Antenna Clip on Loop	50 mmf	1400 kc Index Line. See Note A	R-F (C-6) Antenna (C-2)

