

MOTOROLA

MODELS SK145,163,SKR145,163

CHASSIS HS-1185,1186,1239

CHASSIS REMOVAL

1. Remove back cover by removing screws and pulling cover back to disengage inter-lock plug.
2. Remove record storage compartment by removing screw in bracket at bottom of storage compartment. Compress top edges of compartment to remove it.
3. Disconnect cables, remove chassis mounting screws and lift chassis out. Power amp chassis can be removed by removing screws holding chassis to cabinet bottom and lifting chassis out.

These models are three-channel Stereophonic consoles. SK versions use HS-1186 pre-amp chassis which is very similar to HS-1137 (on page 75); SKR versions use HS-1185 tuner which is very similar to HS-1138; all versions use HS-1239 power amplifier, schematic diagram below.

