


A circuit diagram showing a resistor (zigzag line) and a speaker (trapezoid with a vertical line through it) connected in series.



110 125 150 220 240
 o o o o o
 Frei J F K
 o o o o o
 B F F F
 o o o o o
 E A B A B