



# MOTOROLA

MODELS	CHASSIS
5C15BW	HS-662
5C15GW	HS-662
5C15VW	HS-662

## To Remove Chassis From Cabinet

1. Remove the dial scale, tuning and volume knobs.
2. From rear, remove the 2 rear cabinet mounting screws and pull out rear cabinet.
3. Remove the 4 chassis mounting screws.
4. Unsolder antenna, speaker, and AC power leads.
5. Remove chassis from cabinet.

