



TRANSITONE HOME RADIO MODELS PT-49 AND PT-51

Schem. No.	Description	Philco Part No.
1	Antenna Transformer	32-3168
2	Tubular Condenser (.0015 mf., 200 v.)	30-4555S
3	Tuning Condenser	31-2428
4	Switch	42-1406
5	Tubular Condenser (.05 mf., 200 v.)	30-4519S
6	Tubular Condenser (.15 mf., 400 v.)	30-4505S
7	Resistor (47,000 ohms, ¼ watt)	33-347154
8	Mica Condenser (110 mmf.)	30-1130
9	Oscillator Transformer	32-3167
10	Tubular Condenser (.05 mf., 200 v.)	30-4519S
11	1st I. F. Transformer	32-3149
12	2nd I. F. Transformer	32-3150
13	Resistor (2.2 meg., ¼ watt)	33-522154
14	Mica Condenser (250 mmf.)	61-0033
15	Resistor (22,000 ohms, ½ watt)	33-322334
16	Volume Control (500,000 ohms)	33-5306
17	Tubular Condenser (.01 mf., 200 v.)	30-4479S

Schem. No.	Description	Philco Part No.
18	Resistor (4.7 meg., ¼ watt)	33-547154
19	Resistor (220,000 ohms, ¼ watt)	33-422154
20	Tubular Condenser (.01 mf., 400 v.)	30-4572S
21	Resistor (470,000 ohms, ¼ watt)	33-447154
22	Resistor (130 ohms, ½ watt)	33-113336
23	Tubular Condenser (.04 mf., 400 v.)	30-4119S
24	Output Transformer	
	Part of Speaker No.	36-1469
25	Speaker	36-1469
26	Electrolytic Condenser (20-20 mf., 150 v.)	30-2382
27	Field Coil Part of Speaker No.	36-1469
28	Pilot Lamp	34-2068
29	Line Resistor	33-3367
30	Tubular Condenser (.04 mf., 400 v.)	30-4119S
31	Push Button Switch	42-1485
32	Padding Condenser Strip	31-6293