



# RADIO WIRE TELEVISION

MODEL D-13



LEGEND		50M Ohms		50M Ohms	
C1	0001	R1	330	R2	5M
C2	25	R3	5M	R4	5M
C4	1	R5	5M	R6	5M
C5	1	R7	5M	R8	5M
C6	05	R9	5M	R10	5M
C7	00025	R11	5M	R12	5M
C8	01	R13	5M	R14	5M
C9	1	R15	5M	R16	5M
C10	00025	R17	5M	R18	5M
C11	01	R19	5M	R20	5M
C12	01	R21	5M	R22	5M
C13	001	R23	5M	R24	5M
C14	002	R25	5M	R26	5M
C15	004	R27	5M	R28	5M
C16	0	R29	5M	R30	5M
C17	0	R31	5M	R32	5M
C18	1	R33	5M	R34	5M



## PARTS LIST

- 1924 2 gang condenser  
8036 Power Transformer  
2443 Volume Control  
6922 Switch  
1154 Antenna Coil  
1155 Oscillator Coil  
1123 1st I F  
1124 2nd I F  
1846 Filter Condenser  
243 Pilot Late Bracket  
8901 No 40 Pilot Late  
6850 4 Prong Socket  
6852 6 Prong Socket  
6853 7 Prong Socket  
2006 Padder  
2052 Trimmer  
7104 Tube Shield Base  
7105 Tube Shield  
1500 001-20%  
1501 0001-20%  
1509D 002-5%  
1504 00025-20%  
6016 5 M 1/3 20% Resistor  
6017 1 Meg 1/3 W 20% Resistor  
6018 1/2 Meg 1/3 W 20% Resistor
- 6024 1/4 Meg 1/3 W 20% Resistor  
6025 50 M 1/3 W 20% Resistor  
6058 330 Ohms 1/3 W 10% Resistor  
6057 4500 Ohms 1/3 W 20% Resistor  
6059 190 M 1/3 W 5% Resistor  
6060 600 M 1/3 W 5% Resistor  
6105 10 M 1/2 W 20% Resistor  
6117 25 M 1/2 W 20% Resistor  
1600 1-200 V Bypass Condenser  
1601 1-400 V Bypass Condenser  
1628 01-200 V Bypass Condenser  
1604 01-600 V Bypass Condenser  
1614 25-200 V Bypass Condenser  
1622 05-200 V Bypass Condenser  
1602 1-600 V Bypass Condenser  
1651 004-600 V Bypass Condenser  
Dial (order by name and description)  
7946A Speaker  
5218 Knobs