

- Condenser (.25 Mfd.) 61-0113
- Resistor (150 ohms) 33-11534
- Condenser (.01 Mfd.) 61-0111
- Condenser (.25 Mfd.) 61-0125
- Resistor (2200 ohms) 33-222434
- Resistor (1,000,000 ohms) 33-510154
- Resistor (1,000,000 ohms) 33-510154
- Com-pur (15,000 ohms) 33-327154
- Volume Control (350,000 ohms) 67-0032-2
- Condenser (8000 Mmfd.) 61-0103
- Resistor (15,000,000 ohms) 33-615154
- Resistor (27,000 ohms) 33-327154
- Padder (Pri. 2nd I. F. Trans.)
- Second I. F. Transformer .. 65-0320
- Padder (Sec. 2nd I. F. Trans.)
- Condenser (4000 Mmfd.) 61-0129
- Condenser (250 Mmfd.) 61-0053
- Tone Control Switch 85-0111
- Condenser (250 Mmfd.) 61-0033
- Condenser (.01 Mfd.) 61-0100
- Resistor (470,000 ohms) 33-447164
- Resistor (220,000 ohms) 33-422334
- Filter Condenser (10-15-20 Mfd.) 61-0089
- Resistor (220 ohms) 33-122438
- Condenser (.01 Mfd.) 61-0124
- Output Transformer 65-0317
- Condenser (250 Mmfd.) 61-0033
- Replacement Core (For 73-0045-2 Speaker) 91-0086
- (For 73-0045-3 Speaker) 91-0128
- (For 73-0047-2 Speaker) 91-0086
- (For 73-0047-3 Speaker) 91-0128
- Field Coil Not Replaceable
- Condenser (250 Mmfd.) 61-0033
- Choke 33-1644
- Wafer Switch 77-0367
- Silver Mica Condenser (1650 Mmfd.) 5877
- Silver Mica Condenser (600 Mmfd.) 60-180314
- Padder Assembly 77-0560
- Condenser (.01 Mfd.) 61-0110
- Condenser (70 Mmfd.) 61-0146
- Condenser (1000 Mmfd.) 61-0079
- Antenna Padder (on Tun. Cond.)
- Tuning Condenser 63-0050
- Condenser (50 Mmfd.) 61-0140
- Condenser (200 Mmfd.) 61-0141
- Oscillator Padder (on Tun. Cond.)
- On-Off Switch 83-0112

FOR OTHER DATA, SEE INDEX

- ANT. 11.9 MC.
- ANT. 9.5 MC.
- ANT. 17 MC.
- ANT. 8 MC.
- OSC. 12.1 MC.
- OSC. 10 MC.
- Condenser (250 Mmfd.) 61-0083
- Condenser (.3 Mfd.) 61-0137
- Condenser (250 Mmfd.) 61-0033
- "A" Choke 32-1604
- Vibrator Choke 85-0075
- Condenser (.5 Mfd.) 61-0137
- Vibrator 83-0025
- Resistor (150 ohms) 33-11534
- Resistor (220 ohms) 33-122334
- Power Transformer 65-0318
- Condenser (3000 Mmfd.) 61-0115
- Resistor (1000 ohms) 33-310434

