


2 B 402
Ivory

2 B 405
Red



- a. Observe the position of the battery save button extension in relation to the "battery-save" switch. This extension must engage with the center of the battery save switch.
- b. Replace in reverse order to that given for chassis removal.

