


RCA VICTOR

Models 4VF304, 4VF325, 4VF326, 4VF348, 4VF349, 4VF405, 4VF446, 4VF464, 4VF480, 4VF488, 4VF534, use Tuner Chassis RC-1211A covered across these two pages, and Amplifier Chassis RS-177J or RS-199C which are very similar to amplifier chassis of the number (but different suffix) covered on the preceding page.



RCA VICTOR

Models 4VF304, 4VF325, 4VF326, 4VF348, 4VF349, 4VF405, 4VF446, 4VF464, 4VF480, 4VF488, 4VF534, use Tuner Chassis RC-1211A covered across these two pages, and Amplifier Chassis RS-177J or RS-199C which are similar to amplifier chassis of corresponding number (but different suffix) of previous section.

