


RECORD CHANGER: Model RP-168, on pages RCD.CH.19-1 through RCD.CH.19-8.


RCA

MODELS A78,  
9W78, Ch. RC-1084A



Complete Schematic Diagram

RECORD CHANGER: Model RP-178, on pages RCD.CH.18-14 through RCD.CH.18-23.



Simplified Schematic Diagram  
"FM" Band

RCA MODEL 9W76,  
Ch. RC-1084A

