


CHASSIS ASSEMBLY V-2238-1

MODELS H-499T5A,H-500T5A



Step	Connect Signal Generator to —	Signal Generator Frequency	Radio Dial	Adjust for Maximum Output
1.	Stator of ant. tuning capacitor (A) through a 200 mmf capacitor	455 kc.	Minimum capacity	Top and bottom slugs of T2 and T1 in order given
2.	Same as step 1	1625 kc.	Minimum capacity	Oscillator trimmer (D)
3.	Radiated signal	1400 kc.	1400 kc.	Antenna trimmer (B)