



DIAG NO	PART NO	DESCRIPTION
C1	22-546	TWO GANG VARIABLE
C2	22-407	.05 MFD. 400V.
C3	22-127	25 MMFD. 600V.
C4	22-350	.002 MFD. 600V.
C5	22-563	FIXED PADDER
C6	22-170	.1 MFD. 400V.
C7	22-162	.0001 MFD. 600V.
C8	22-185	.01 MFD. 200V.
C9	22-327	.02 MFD. 200V.
C10	22-147	.0005 MFD. 600V.
C11	22-190	.1 MFD. 200V.
C12	22-435	.02 MFD. 600V.
C13	22-492	.002 MFD. 600V.
C14	22-171	.05 MFD. 600V.
C15	22-596	.08 MFD DRY ELECTROLYTIC 450V
C16	22-596	.14 MFD DRY ELECTROLYTIC 450V
VARIABLE TRIMMERS		
A	131	I.F. TRANS. PRIMARY
B	131	I.F. TRANS. SECONDARY
C	22-519	I.F. TRANS. PRIMARY
D	22-519	I.F. TRANS. SECONDARY
E	22-570	WAVE TRAP
F	22-570	BROADCAST OSCILLATOR (SEE NOTE)
H	22-519	ANTENNA BROADCAST (ON GANG)
J	22-519	BROADCAST PADDER
K	22-519	SHORT WAVE OSCILLATOR (SEE NOTE)
L	22-305	SHORT WAVE DETECTOR
TRIMMERS F & K MOUNTED ON BAKELITE STRIP #22-408		

DIAG NO	PART NO	DESCRIPTION
R1	63-593	47 M OHM 1/4 W ± 20%
R2	63-589	10 M OHM 1/4 W ± 20%
R3	63-610	22 M OHM 1 W ± 20%
R4	63-677	33 M OHM 1 W ± 10%
R5	63-271	1 MEG OHM 1/4 W ± 20%
R6	63-565	400 M OHM VOLUME CONTROL
R7	63-296	220 M OHM 1/4 W ± 20%
R8	63-597	470 M OHM 1/4 W ± 20%
R10	63-613	3 SECTION CANDO HM 50-60 Ω
R11	63-806	3 SECTION CANDO HM 25 Ω
1		WAVE TRAP COIL MOUNTED ON ANTENNA COIL ASSEMBLY
2	5-4934	ANT COIL & SHIELD ASSEMBLY
3	5-4909	OSCILLATOR COIL ASSEMBLY
4	95-407	131 I.F. TRANSFORMER
5	95-408	22-519 I.F. TRANSFORMER
6	95-104	BAND SELECTOR SWITCH
7	95-406	POWER TRANSFORMER
8	95-452	117 VOLT 50-60 CYCLE POWER TRANSFORMER
9		ALL VOLTAGE 25 CYCLE SPEAKER TRANSFORMER

MODEL	SPEAKER
5-S-218	49-178 5"
5-S-220	49-178 5"
5-S-228	49-178 5"
5-S-237	49-180 6"
5-S-250	49-179 8"
5-S-252	49-208 10"

Models 5-S-201, 5-S-218,
5-S-220, 5-S-228,
5-S-237, 5-S-250, 5-S-252
(5521 Chassis)

I.F.-FREQUENCY 456 K.C.
5 TUBE SUPERHETERODYNE
2 BAND
CHASSIS NO 5521

ZENITH RADIO CORP.