



Operation	Connect Oscillator To	Dummy Antennas	Input Sig. Frequency	Set Disl At	Trimmers	Purpose
1	Converter Grid	.5 Mfd.	455 Kc.	600 Kc.	L4,L5,L6, L7	For I.F. Align- ment.
2	One Turn Loop Coup- led Loosely to Wave- magnet	—	1600 Kc.	1600 Kc.	C1F	Set Oscillator to Disl Scale.
3		—	1400 Kc.	1400 Kc.	C1D, C1B	Align Detector and Antenna Stsge.