


MODEL H-204A,
CHASSIS
V-2128-4



NOTE

- 1 VOICE COIL DISCONNECTED.
- 2 SELECTOR SWITCH SW2 SW3 SHOWN IN EXTREME COUNTER CLOCKWISE POSITION OR AM BAND SECOND POSITION CLOCKWISE IS FM BAND.
- 3 ALL VOLTAGES MEASURED FROM CHASSIS (GND) USING 20,000 OHM/VOLT METER—LINE VOLTAGE 117 V A C VOLTAGES SHOULD BE AS SHOWN \pm 20 PER CENT

CHASSIS NO V-2128-4