

# Models WR-12X3, 12X5 & 12X6




## Five-Tube, Single-Band, AC-DC, Superheterodyne Receiver

### Alignment Procedure

**Output Meter Alignment.**—If this method is used connect the meter across the voice coil and turn the receiver volume control to maximum.

**Test Oscillator.**—Connect the low side of the test oscillator to the receiver chassis through a .01 mfd. capacitor. With the output meter alignment method the test oscillator output should be kept as low as possible.

**Calibration Scale.**—The glass tuning dial may be easily removed from the cabinet and temporarily attached to the dial backing plate for quick reference during alignment.



Tube and Trimmer Locations

Steps	Connect the high side of test-oscillator to—	Tune test-osc. to—	Turn radio dial to—	Adjust the following for max. peak output—
1	I-F grid, in series with .01 mfd.	455 kc	Quiet point 1,600 kc end of dial	C10, C9 2nd I-F Transformer
2	1st Det. grid in series with .01 mfd.			C8, C7 1st I-F Transformer
3	Ant. terminal in series with 100 mmfd.	1,720 kc	Gang at minimum	C14 (osc.)
4	Radiated signal 1,300 kc		Signal frequency	C15 (ant.)
5	Repeat steps 3 and 4.			

