


ZENITH RADIO MODELS HF110G & J CHASSIS 3Z04



MODELS HF 110, G & J CABINET PARTS
Using Chassis 3Z04
DESCRIPTION

PART NO.	QTY	DESCRIPTION
14-2405G		Table Cabinet - Model HF110G
14-2405J		Table Cabinet - Model HF110J
19-298		Mounting Clip (mts. S-41437)
24-923		Chassis Cover - Model HF110J
24-924		Chassis Cover - Model HF110G
36-210		Cabinet Handle (part of 14-2405G)
36-211		Cabinet Handle (part of 14-2405J)
40-157		Lid Support Hinge (part of 14-2405, G & J)
40-189		Hinge (2 part of 14-2405 G & J)
46-1318		Knob - Volume & Tone HF110J
46-2001		Knob - Volume & Tone HF110G
49-795	SP1	7½" P.M. Speaker
83-765		Armite strip (2 used)
83-1475		Armite strip
83-2535		Phono Shipping Strip (2 used)
83-2761		Phono Shipping Strip
86-254		Terminal (4 used)
93-1173		6 Finishing Washer (1 used on ea. 70-239)
93-1260		Fibre Washer (2 part of S-14083)
142-87		Dual Cartridge (Sapphire-Sapphire)
156-45		Cover Latch (2 part of 14-2405J)
159-94		Plug Button (4 used on 14-2405G & J)
159-95		Plug Button Screen (2 used on 14-2405 G & J)
166-114		Plastic Bumper (4 part of 14-2405 G & J)
188-102		Knob Retaining Ring (1 part of ea. S-43478, 43479, 44126 & 44127)
188-195		Retaining Ring (2 part of S-14083)
202-1362		Instruction Book
S-14083		Record Changer
S-23829	SP2, 3	Tweeter Speaker (2 used)
S-41437		45 RPM Record Adapter
S-42308		Cartridge Holder (part of S-14083)
S-43478		Knob & Ring Assem.
S-43479		Knob & Ring Assem.
S-44126		Knob Ring Assem. Tone HF110G
S-44127		Knob & Ring Assem. Dummy HF110G

